

# Business Mobility DECT Cordless Handset C124

USER GUIDE



Published by:

**NEC PHILIPS UNIFIED SOLUTIONS  
HILVERSUM, THE NETHERLANDS**

Order number: **9600 017 67000**  
User Guide C124

Date: Sept 2008

Great care has been taken to ensure the accuracy and completeness of the information contained in these operating instructions.

If, however, you should find a mistake or an omission, or have a suggestion aimed at improving this User Guide, then please inform us at the following address:

**NEC PHILIPS UNIFIED SOLUTIONS  
P.O. BOX 32  
1200 JD HILVERSUM  
THE NETHERLANDS**

© NEC Philips Unified Solutions 2008

All rights reserved. No part of these operating instructions may be reproduced without the prior written permission of the copyright owner.

## Notice to the user

The DECT handset described in this manual should only be used in combination with DECT systems delivered by NEC Philips. In order to take advantage of all features described in this manual the country and network provider specific features should match the features of the NEC Philips system.

### Important safety information

The mains voltage of the power adaptor should match the local mains voltage, which must be in the range of 100-240Vac. Check if both voltages match before installing the charger and adaptor.

Only use adaptor and battery pack that is supplied with the package.  
Use only supplied charging cradle for recharging the handset batteries.

Do not disassemble this product, it contains no user-serviceable parts.  
In case of a thunderstorm, it is advised to disconnect the power adaptor.

Do not expose this product to dust, strong sunlight, humidity, high temperature or mechanical shock.  
Do not use corrosive or abrasive cleansers on this product. Keep the unit dust free by wiping it with a soft, dry cloth.

### Sensitive Electronic Environment

Any radio-based equipment can potentially cause interference with other equipment and can be interfered from other equipment. This also applies for DECT equipment. However due to the very low transmission power level the chances for interference are very small. Research proves that operational DECT phones normally don't influence electronic equipment however some precautions must be taken into account for sensitive electronic equipment e.g. sensitive laboratory equipment. When DECT phones operate in straight nearness of sensitive electronic equipment incidental influence can appear. You are advised not to place the DECT phone on or close (less than 10cm) to this kind of equipment, even in standby mode. Please also use the other documentation supplied with the various parts of your telephone system.

### Electric, Magnetic and Electromagnetic Fields ("EMF")

Our products, like any electronic apparatus, have the ability to emit and receive electro magnetic signals. One of our leading business principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

NEC Philips is committed to develop, produce and market products that cause no adverse health effects. NEC Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

NEC Philips plays an active role in the development of international EMF and safety standards, enabling NEC Philips to anticipate further developments in standardization for early integration in its products.

# Contents and Accessories

The following items are included in the package:


- Handset unit.
- Charger unit.
- Rechargeable AAA size NiMH batteries (1.2V 600mAh, 3 pieces).
- Power supply unit.

## Handset

1. LCD screen
2. Keypad
3. Ear piece
4. Microphone
5. Battery compartment cover
6. Handset charge contacts
7. Headset jack


## Charger Unit

8. Charger charge contacts
9. Power indication
10. AC adaptor



## Installation and Start-Up

1. Check if the mains voltage matches the adapter mains voltage.
2. Plug the AC adapter into the mains socket-outlet.
3. On the handset, gently slide & open the battery cover and insert the rechargeable batteries supplied with the package. The + - poles of the batteries must correspond to the + - markings in the battery compartment.



4. Replace the battery cover by sliding it back into place.
5. Put the handset onto the charger unit. Make sure charge indicator on the handset unit animates to show charging in progress.

### **IMPORTANT NOTICE :**

To obtain best battery performance, charge the handset for 12 hours before initial use. Defect handsets or defect or exhausted batteries should never be disposed of as municipal waste. For more information refer to the chapter "Environmental protection".

6. Subscribe the handset to the DECT system using the Registration Menu in the Main Menu.











## Display Arrangement



Extra display line for dialed digits, calling number, etc.

Symbol	Indication
	Received signal strength. If the handset is out of range the display shows: SEARCHING...
	Keypad lock is activated
	On: handset is off hook. Flashing: incoming call.
	The handset speakerphone mode is activated.
	The handset microphone is muted.
	Battery capacity. During charging, it is an animated icon.
	A voice message is waiting.
	The handset is in standby mode. The handset name will be displayed if it is programmed.






# Keypad Arrangement

Button	In Standby	In Conversation	In Menu Mode
R  ON	Make or answer a call. When switched off: switch on the handset.	Enquiry / Call transfer.	Start dialing from phone book, redial list, or caller ID list.
 OFF	Long press this button to switch off the handset.	End a call.	Return to standby mode.
<b>0 – 9</b>	Enter digit 0-9.	Send DTMF signal 0-9.	To enter digit 0-9
	Enter call log.	Increase receiver volume.	Scroll through menu items.
 	Enter telephone book	Decrease receiver volume.	Scroll through menu items.
OK 	Enter menu mode.	Not used	Confirm an action or selection.
 	Enter redial list.	Toggle speakerphone mode.	Toggle upper/lower case in phone book mode.
 	Not used.	Toggle microphone mute.	Go back to previous menu or cancel an action.
<b>#</b>	Press and hold to insert pause.	Enter DTMF #.	Press and hold to insert pause in phonebook entries.

# Normal Operation

## Making a Call

Making a call can be done as follows:



- Press  and dial a number
- Pre-dial a number and press 
- Select a number from the phonebook and press 
- Select a number from the redial list and press 
- Select a number from the caller list and press 

## Receiving a Call

An internal call is indicated by the INT icon on the display and the internal ring tone.

An external call is indicated by the external ring tone.




The caller's number is displayed if it is made available by the PBX. If the caller's number is present in the phonebook the caller's name is displayed.

Answer an incoming call by pressing  or by pressing  for handsfree operation.


An incoming call can be rejected by pressing 

After answering a call the call duration time is displayed.



## Enquiry Call / Call Transfer

During a telephone conversation press  to hold the call and dial another number. Press  again to switch back to the first caller. Press  to transfer the call.

## Ending a call





End a call by pressing 

## Keypad Lock

In idle mode the keypad can be locked by pressing  followed by   
Repeat this key combination to unlock the keypad.





When the keypad is locked incoming calls can be answered.

# Menu Functions


All essential functions of this handset can be programmed via the Menu  / **OK** button, the Up/Down arrow buttons  /  and the backspace button . The following menu items are available:

## Caller List

The number of an incoming call is displayed by the handset when available. If the number is present in the phone book, the related name will be displayed. The last 10 callers are stored. The oldest record is replaced by newest record. Unread records are marked with a "\*" character.

To enter the caller list press  or enter the menu by pressing  and select CALLER LIST. Press  /  to scroll through the list. The following functions are available:

### Call Back

Select a number from the list and press 

### Copy to Phonebook

Select a number from the list and press **OK**, select COPY TO PHB, and press **OK**.



You are prompted to edit the number and add a name.

### Delete All

You can delete the complete caller list. When viewing the list press **OK**, select DELETE ALL and press **OK**.

## Phonebook

There are 40 phone book entries (12 characters and 24 digits).

To enter the phonebook press  or enter the menu by pressing  and select PHONEBOOK. The following functions are available:

### Create Entry

In the phonebook scroll to NEW ENTRY and press **OK**.

The display shows EDIT NUMBER.

Use the alphanumeric buttons (0 to 9) to enter a number and press **OK** to confirm.

The display shows EDIT NAME.

Use the alphanumeric buttons (1-9) to enter a name and press **OK** to confirm.

Use button (0) to enter a space. Press  to switch between upper and lower case.

### Delete Entries

In the phonebook select an entry and press **OK**.

Select DELETE to delete a single entry or DELETE ALL to delete all phonebook entries, press **OK** to confirm.


### Modify Entry

In the phonebook select an entry and press **OK**.

Select EDIT and press **OK**.

You are prompted to modify the number and the name. Confirm with **OK**.

## Redial List

To enter the redial list press  or from the main menu select REDIAL and press **OK**.

The following functions are available:

### Copy to Phonebook

In the redial list select an entry and press **OK**.

Select COPY TO PHB and press **OK**.

You are prompted to modify the number and the name. Confirm with **OK**.

### Delete All

In the redial list select an entry and press **OK**.

Select DELETE ALL to delete all entries, press **OK** to confirm.

## Tone Setup

In the main menu select TONE SETUP and press **OK**.

In the Tone Setup menu the following settings can be changed:

### Silent Charging mode

In silent charging mode the handset will not ring when placed on the charger.

Toggleing this mode is done as follows:

In TONE SETUP menu select SILENT CHG. and press **OK**.

Select ON or OFF and press **OK**.

### External Melody

Used to change the ring melody for external calls.

In TONE SETUP menu select EXT. MELODY and press **OK**.

Scroll through the list and select the required melody by pressing **OK**.

### Internal Melody

Used to change the ring melody for internal calls.



In TONE SETUP menu select INT. MELODY and press **OK**.

Scroll through the list and select the required melody by pressing **OK**.

### Ring Volume

Used to change the ring volume for all calls.

In TONE SETUP menu select RING VOLUME and press

Use / to modify the ring volume and confirm by pressing **OK**.

### Key Tone

Toggleing key tones is done as follows:

In TONE SETUP menu select KEY TONE and press **OK**.

Select ON or OFF and press **OK**.

## Handset Name

The handset name is displayed in idle mode.  
Changing the handset name is done as follows:  
In the main menu select HS NAME and press **OK**.  
You are prompted to edit the handset name. Confirm with **OK**.

## Registration Menu

This handset can be registered to only a single DECT system. The following functions are available.



### Subscribe

Subscribe the handset to the DECT system.  
First prepare the subscription in the DECT system.  
In the registration menu select SUBSCRIBE and press **OK**.  
You are prompted to enter the pin code, confirm with **OK**.

### Cancel HS

The normal way to remove a subscription is via the DECT system. This will also remove the subscription from the handset. If this is not possible the subscription can be removed from the handset as follows:  
In the registration menu select CANCEL HS and press **OK**.  
You are prompted to confirm this action.

## Answer Mode

The handset can be programmed to answer a call with key  or  (normal mode) or with any key.  
In the ANSWER MODE menu select NORMAL or ANY KEY and confirm with **OK**.


## Language

In the language menu scroll to the required language and confirm with **OK**.

# Environmental protection

## Product disposal information

For countries in the European Union



In order to facilitate separate disposal and environmentally sound recycling NEC Philips Unified Solutions has made arrangements for local collection and recycling in all member states of the European Union. In case your electrical and electronic products need to be disposed of please refer to the contractual agreements that your company has made upon acquisition of these products. Should this information not be available, please contact the local NEC Philips organization or contact us at : [www.nec-philips.com/weee](http://www.nec-philips.com/weee)

### For countries outside the European Union

Disposal of electrical and electronic products in countries outside the European Union should be done in line with the local regulations. If no arrangement has been made with NEC Philips Unified Solutions or your supplier, please contact the local authorities for further information.

## Battery disposal information

Defect or exhausted batteries should never be disposed of as municipal waste. Return old batteries to the battery supplier, a licensed battery dealer or a designated collection facility. Do not incinerate batteries.

This product uses rechargeable NiMH batteries. Do not use any other type. For battery replacement or removal please remove the battery cover as described in chapter "Installation and start-up".

# Declaration of conformity (European Union)

## Česky

"NEC Philips Unified Solutions" tímto prohlašuje, že tento C124 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

☐ <http://www.nec-philips.com/doc>

## Dansk

Undertegnede "NEC Philips Unified Solutions" erklærer herved, at følgende udstyr C124 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

☐ <http://www.nec-philips.com/doc>

## Deutsch

Hiermit erkläre "NEC Philips Unified Solutions", dass sich das Gerät C124 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

☐ <http://www.nec-philips.com/doc>

## Eesti

Käesolevaga kinnitab "NEC Philips Unified Solutions" seadme C124 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

☐ <http://www.nec-philips.com/doc>

## English

Hereby, "NEC Philips Unified Solutions", declares that this C124 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

☐ <http://www.nec-philips.com/doc>

## Español

Por medio de la presente "NEC Philips Unified Solutions" declara que el C124 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

☐ <http://www.nec-philips.com/doc>

## Ελληνική

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η ΝΕC Philips ΕΝΟΠΟΙΗΜΕΝΕΣ ΛΥΣΕΙΣ ΔΗΛΩΝΕΙ ΟΤΙ C124 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

☐ <http://www.nec-philips.com/doc>

## Français

Par la présente "NEC Philips Unified Solutions" déclare que l'appareil C124 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

☐ <http://www.nec-philips.com/doc>

## Íslenska

Hér með lýsir "NEC Philips Unified Solutions" yfir því að C124 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

☐ <http://www.nec-philips.com/doc>

## Italiano

Con la presente "NEC Philips Unified Solutions" dichiara che questo C124 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

☐ <http://www.nec-philips.com/doc>

## Latviski

Ar šo "NEC Philips Unified Solutions" deklarē, ka C124 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

☐ <http://www.nec-philips.com/doc>

## Lietuvių

Šiuo "NEC Philips Unified Solutions" deklaruojama, kad šis C124 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

☐ <http://www.nec-philips.com/doc>



**Malti**

Hawnhekk, "NEC Philips Unified Solutions", jiddikjara li dan C124 jikkonforma mal-ftigijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

☐ <http://www.nec-philips.com/doc>

**Magyar**

Alulírott, "NEC Philips Unified Solutions" nyilatkozom, hogy a C124 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

☐ <http://www.nec-philips.com/doc>

**Nederlands**

Hierbij verklaart "NEC Philips Unified Solutions" dat het toestel C124 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

☐ <http://www.nec-philips.com/doc>

**Norsk**

"NEC Philips Unified Solutions" erklærer herved at utstyret C124 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

☐ <http://www.nec-philips.com/doc>

**Polski**

Niniejszym, "NEC Philips Unified Solutions" deklaruje, że C124 jest zgodny z wymaganiami i innymi warunkami Dyrektywy 1999/5/EC.

☐ <http://www.nec-philips.com/doc>

**Português**

"NEC Philips Unified Solutions" declara que este C124 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

☐ <http://www.nec-philips.com/doc>

**Slovensko**

"NEC Philips Unified Solutions" izjavlja, da je ta C124 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

☐ <http://www.nec-philips.com/doc>

**Slovensky**

"NEC Philips Unified Solutions" týmto vyhlasuje, že C124 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

☐ <http://www.nec-philips.com/doc>

**Suomi**

"NEC Philips Unified Solutions" vakuuttaa täten että C124 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

☐ <http://www.nec-philips.com/doc>

**Svenska**

Härmed intygar "NEC Philips Unified Solutions" att denna C124 står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

☐ <http://www.nec-philips.com/doc>

NEC PHILIPS Unified Solutions  
Anton Philipsweg 1  
1223 KZ Hilversum  
The Netherlands



## FCC Rules (United States)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect equipment into an outlet on a circuit different from that to which receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment: SAR 0.0560 W/kg (Normal use), SAR 0.017 W/kg (Pocket/Belt use).

Privacy of communications may not be ensured when using this phone.